

Operating Manual Vegetable Cutter

ANLIKER XXL

Translation of the German Original





Table of contents

1 AN	NLIKER XXL - Introduction					
1.1	Operating manual5					
1.1.1	Scope of applic	cation			5	
1.1.2	Target group a	nd mandatory readin	g		5	
1.1.3	Warnings and	instructions for use	-		6	
1.1.4	Abbreviations	and symbols			6	
1.2		•				
1.3	Device identifi	cation			7	
2 Sa	fetv				7	
2.1	•					
2.2	Intended use					
2.3	•	-				
3 St	•					
3.1						
3.2						
3.3					-	
3.4	• •					
3.5						
3.6						
3.7						
••••		-				
4 St		•				
4.1						
	•					
4.3		-				
4.4	-	-				
4.5	•					
4.6	•					
4.7	-	•				
4.8						
4.9	-					
5 Ins						
5.1		-		cing inserts		
5.1.1	Preparation of	the ANLIKER XXL for	food processing		21	
5.1.2	Inserting the e	jector or ejector disc.			21	
5.1.3	Insertion of cu	tting or grating disc			22	
5.1.4	Close the attac	hment			22	
5.1.5	•					
5.1.6	Inserting the d	icer grid			23	
5.2	Cutting vegetables					
5.3	Using the accessories (Multifeeder insert)					
5.3.1	Preparing the device for the Multifeeder					
5.3.2						
5.3.3	Changing the Multifeeder cutting disc					
5.4	Using the accessories (neutral blade)					
5.4.1	-	-	-			
5.4.2						
Generat		Reviewed:	Revised:	Status: 300 released	Page 2 of 41	
Ralph N			Ralph Moretti	Document number:	Index	
28 July 2	2021		20.01.2025	235.01550	CA	



swiss 🚹 made

6	Sy	stem care "cleaning concept"	28
6.1		Cleaning the ANLIKER XXL vegetable cutter	28
6.2		Removing the top	28
6.3		Cleaning the cutting discs, grating discs and dicing inserts (W)	29
6.3.	1	Cleaning the dicer grid	29
6.3.	2	Residues in the dicer grid	29
6.3.	3	Manual cleaning of the dicer grid	29
7	Μ	ounting the cutting disc holder	31
8	Tr	oubleshooting	32
8.1		Elimination of malfunctions	32
8.1.	1	Device does not run	.32
8.1.	2	Device clogged	.32
8.1.	3	The dicing insert W (dicer knife and grid) cannot be removed	.32
8.1.	4	The cutting quality (surface structure) keeps deteriorating	.32
8.1.	5	The knife does not move freely	.32
8.1.	6	Cutter bar broken	
8.1.	7	The device can no longer be switched off	.33
8.1.	8	Service opening	.33
8.2		Service and information	33
9	Ar	nex	34
9.1		Spare parts	34
9.2		Disposal	34
9.3		Device transfer to third parties	35
9.4		Technical Specifications	35
9.5		Warranty	35
9.6		Documents	
9.6.	1	Dimensional drawing ANLIKER XXL	36
9.6.	2	CE Conformity Declaration	37
9.6.	3	CE Conformity Declaration for accessories	
9.6.		Supplement 1935/2004	
9.6.		Supplement	
9.6.	6	Supplement	41

List of tables

Table 1: Nameplate	7
Table 2: Components of the basic unit	9
Table 3: Basic unit with funnel	10
Table 4: EMERGENCY OFF and ON/OFF button	13
Table 5: Button	13
Table 6: Technical specifications ANLIKER XXL	35

Generated:	Reviewed:	Revised:	Status: 300 released	Page 3 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



List of illustrations

Fig. 1: Nameplate	7
Fig. 2: Components of the basic unit	9
Fig. 3: Funnel attachment	10
Fig. 4: ANLIKER XXL	
Fig. 5: Accessories kit	
Fig. 6: Ejector	11
Fig. 7: Standard screw blade	11
Fig. 8: ANLIKER XXL PRO attachment piece	
Fig. 9 Ejector disc	
Fig. 10 Neutral blade	12
Fig. 11: Various cutting discs, grating discs,	
Fig. 12: Multifeeder insert Dicing inserts (W)	12
Fig. 13: Emergency OFF and ON/OFF button	13
Fig. 14 Parking brake locked in place	14
Fig. 15: Power cable	16
Fig. 16: Insert the attachment piece and lock	19
Fig. 17: Locking the newly attached piece	19
Fig. 18 Inserting the screw blade	20
Fig. 19: Mounting the funnel	20
Fig. 20: IN / OUT direction	20
Fig. 21: Fastening the funnel	20
Fig. 22: Safety lock closed	20
Fig. 23: Lock the funnel	21
Fig. 24: Locked funnel	21
Fig. 25: Tilted funnel and attachment piece	21
Fig. 26: Inserted ejector	21
Fig. 27: Inserted cutting disc	22
Fig. 28: Inserted screw blade	22
Fig. 29: Locked funnel	22
Fig. 30: Dicer grid indent Fig. 31:Upper part pin	23
Fig. 32: Inserted dicer grid	23
Fig. 33: Filling with vegetables	24
Fig. 34: Rocking the screw blade	24
Fig. 35: Cover mounted onto the outlet	25
Fig. 36: Inserting the Multifeeder	26
Fig. 37: Ring for the neutral blade	27
Fig. 38: Insert the neutral blade plunger	27
Fig. 39: Plunger operation	27
Fig. 40: Cutting disc holder	31
Fig. 41: Wall-mounted cutting disc holder	31
Fig. 42: Mounting the cutting disc holder	31
Fig. 43: Service opening	33
Fig. 44: Dimensional drawing ANLIKER XXL	36
Fig. 45: CE Conformity Declaration	37
Fig. 46: Conformity Declaration for accessories	38
Fig. 47: Supplement 1935/2004	39
Fig. 48: Supplement 10/2011	40
Fig. 49: Supplement WEEE	41

Generated:	Reviewed:	Revised:	Status: 300 released	Page 4 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



1 ANLIKER XXL - Introduction

This chapter informs on the scope of application and structure of the operating manual.

1.1 Operating manual

This operating manual enables the correct use and safe application of the ANLIKER XXL vegetable cutter made by Brunner-Anliker AG.

Important: The operating manual must be readily accessible for all users of the ANLIKER XXL vegetable cutter and therefore kept close to the machine.

1.1.1 Scope of application

This operating manual applies exclusively to the ANLIKER XXL vegetable cutter made by Brunner-Anliker AG.

Date of issue of this operating manual: 08.2021

The manual provides instructions on the preparation, operation and maintenance of the fully functional vegetable cutter and information on how to eliminate malfunctions. It is not meant, however, for the execution of repairs of cutter defects. If repairs become necessary, please contact your supplier or the manufacturer.

1.1.2 Target group and mandatory reading

The operating manual addresses all users of the ANLIKER XXL vegetable cutter.

Mandatory reading

All users are to read section 2 "Safety", page 7, before they start working with the ANLIKER XXL vegetable cutter.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 5 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



1.1.3 Warnings and instructions for use

Please observe the following warning symbols and instructions for use.

HAZARD



HAZARD

Indicates that **death or serious physical injury will occur** if the respective precautions are **not** taken.

WARNING



WARNING

Indicates that **death or serious physical injury may occur** if the respective precautions are **not** taken.

CAUTION



Indicates that **minor bodily injury or damage to property may occur** if the respective precautions are **not** taken.

NOTE

NOTE

CAUTION

User information for technically correct and efficient use of the product or for better understanding of the product characteristics.

1.1.4 Abbreviations and symbols

We use abbreviations and easy to recognize symbols at the page margins only for measuring units and the above mentioned warning and usage symbols. (Examples: see "Warnings and instructions for use", page 6).

In this manual, the ANLIKER XXL vegetable cutter will also be referred to as the "device".

1.2 Manufacturer address

Brunner-Anliker Maschinen AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Switzerland

Phone: Mail: +41 44 804 21 00 mail@brunner-anliker.com

Generated:	Reviewed:	Revised:	Status: 300 released	Page 6 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



1.3 Device identification

Please indicate the device ID stamped on the nameplate attached to the side of the ANLIKER XXL vegetable cutter for all inquiries and spare part orders. This will help us to answer your questions fast and correctly.

Information on the nameplate necessary for device identification (example):




Fig. 1: Nameplate

ltem	Item	
1 Producer / contact data	5 Item number	
2 Serial number	6 Date of manufacture	
3 Device name	7 Motor performance characteristics	
4 Certification		

Table 1: Nameplate

2 Safety

This chapter provides information on the general safety guidelines that need to be observed when handling and working with the ANLIKER XXL vegetable cutter.

2.1 Intended use

The intended use of the ANLIKER XXL vegetable cutter is the cutting and slicing of different types of vegetables in the catering and food processing industry. With the various cutting discs, the vegetables can be cut into different shapes and sizes. Only original cutting discs and dicing inserts and spare parts recommended by the manufacturer may be used.

The intended use includes the compliance with the manufacturer instructions and conditions for installation, startup, maintenance and operation of the vegetable cutter.

Any use that does not comply with the intended one and in particular the use of third-party or defective cutting discs is, without prior written consent given by the manufacturer, considered as contrary to its intended use. The manufacturer cannot be held liable for damages resulting from improper use of the ANLIKER XXL vegetable cutter.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 7 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



2.2 General safety guidelines

The following safety guidelines apply to the handling of the ANLIKER XXL vegetable cutter:

- Every user is responsible for his own safety and health. The user is not allowed to carry out jobs whose risk he cannot assess. Such jobs need to be executed by persons qualified accordingly.
- All those working with the ANLIKER XXL vegetable cutter must have been instructed on its use, read and understood the manufacturer's operating manual. See also "User requirements", page 8.
- The instructions provided in this operating manual must be adhered to.
- The user is obligated to operate the ANLIKER XXL vegetable cutter in its fully functional state only and eliminate changes or defects, especially when related to safety issues, immediately.
- It is expressly prohibited to remove or alter safety devices and protective covers.

2.3 User requirements

All those handling the device must have been instructed on its use beforehand. Any specific special training is, however, not necessary.

CAUTION



CAUTION

Risk of injury if handled inexpertly! All those working with the ANLIKER XXL vegetable cutter need to have read and understood the operating manual or be instructed by experienced users prior to its utilization.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 8 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



3 Structure

This chapter informs on the structure and accessories of the device.

3.1 Structure of the basic unit

The ANLIKER XX consists of a basic unit which rests on wheels, and a detachable top. Depending on the top, the device can be used for different jobs.

The basic unit houses the drive with power supply and the control elements. Figure 2 shows the basic unit and its single system components.

The pictures serve as examples.

For dimensional details, please refer to the dimensional drawing (Fig. 44).



Fig. 2: Components of the basic unit

lte	em	Item	
1	Holder frame	5 Outlet with safety cover	
2	Control elements	6 Upper part	
3	Power cable with holder	7 Cutting disc holder	
4	Caster wheels with parking brake	8 Fixed wheels	

Table 2: Components of the basic unit

Generated:	Reviewed:	Revised:	Status: 300 released	Page 9 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



3.2 Basic unit with funnel

Funnel and tray are attached to the holder piece of the basic unit. The tray feeds the products directly into the machine where they are processed immediately.




Fig. 3: Funnel attachment

lte	m	ltem
1	Filler spout - tray	6 Funnel
2	Holder piece with inserted funnel	7 Screw blades
3	Cutting disc holder	8 Funnel lock
4	Power cable with holder	9 Outlet with cover (guard)
5	Caster wheels with parking brake	10 Fixed wheels

Table 3: Basic unit with funnel

Generated:	Reviewed:	Revised:	Status: 300 released	Page 10 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



3.3 Equipment

The customer can configure the device with different cutting discs, grating discs and dicing inserts. The basic unit always comes with funnel attachment, operating manual and cleaning brush.

Fig. 4: ANLIKER XXL

XXL

Fig. 5: Accessories kit Fig. 6: Ejector









Fig. 7: Standard screw blade

Generated:	Reviewed:	Revised:	Status: 300 released	Page 11 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



3.4 Accessories

The ANLIKER XXL can be equipped with an optional PRO attachment. Supplementary accessories plus a large variety of cutting and grating discs as well as disc holders can be ordered from your sales partner or directly at our webshop. Please contact your distributor or visit our website for more information.



Fig. 8: ANLIKER XXL PRO attachment piece Fig. 9 Ejector disc

Fig. 10 Neutral blade



Fig. 11: Various cutting discs, grating discs, Dicing inserts (W)



Fig. 12: Multifeeder insert

Generated:	Reviewed:	Revised:	Status: 300 released	Page 12 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



3.5 Materials

All housing parts and top are made of chromium steel.

3.6 Control elements for activation and deactivation

ANLIKER XXL vegetable cutter operating concept:

- 1. Connect the device to the power outlet ("Electrical / electronic configuration", page 16) and ensure that the EMERGENCY OFF pushbutton is unlocked (item 3 on page 9)..
- 2. Attach the components (tray or funnel) correctly and lock. Check the lock and holder reed switch for correct locking.
- 3. Start cutting by engaging the locking lever and pressing the red button. The button changes from red to green.

The cutting disc starts rotating.




Fig.	13:	Emergency	OFF	and	ON/OFF	button
------	-----	-----------	-----	-----	--------	--------

EMERGENCY - OFF button Button red: OFF Button green: ON	lte	m
	1	EMERGENCY - OFF button
3 Button green: ON	2	Button red: OFF
	3	Button green: ON

Table 4: EMERGENCY OFF and ON/OFF button

3.7 Button switching status

	The device is running	
flashing	The device is ready for operation	
	The device is connected	
flashing	A problem occurred	Separate from the power supply. When the light goes out, re-connect to the power supply.

Table 5: Button

Generated:	Reviewed:	Revised:	Status: 300 released	Page 13 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



4 Structure of the ANLIKER L vegetable cutter

4.1 Unpacking and installation

The device is consigned in a transport box.

Move the device out of the transport box on a makeshift ramp of sheet metal or wooden boards.

CAUTION



Tipping hazard The device weighs around 100 kg and may fall over when moved out of the box. We strongly recommend that the device is moved out of the box and down the makeshift ramp by two people.

Watch the center of gravity.

Or transport the device by means of a stacker truck. To avoid damage, place wooden boards under the device and ensure that no cables get stuck.

The ANLIKER XXL vegetable cutter should not be lifted and transported by hand. If, however, manual lifting and transporting is inevitable, always work in two and lift the device at its holder rail.

The ANLIKER XXL vegetable cutter has two fixed wheels and two caster wheels with brakes. Engage the caster wheel brake catches before carrying out any jobs on or with the device and release them only if the vegetable cutter needs to be moved.

Place the device on a plane and stable surface. Make sure to leave enough space on all sides for safe operation.



Abb. 14 Parking brake locked in place

4.2 Consignment

The ANLIKER XXL vegetable cutter was cleaned at the manufacturer before dispatch. We recommend, however, to clean the device prior to its first use with a food grade cleaning product.

4.3 Reporting Damage

Notify the forwarder, insurance agent, supplier / service center immediately If the vegetable cutter is consigned damaged due to insufficient packaging or inadequate transport. The contact addresses are listed on pages 6 and 33.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 14 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



4.4 Weight of the ANLIKER XXL vegetable cutter

The vegetable cutter weighs 100 kg.

NOTE

Note

- Check the consignment for completeness. Compare the contents with the delivery note. If components are missing, please contact your supplier.
- Notify our after-sales service, the forwarder and the insurance agent immediately if the device is consigned damaged due to insufficient packaging or inadequate transport.



CAUTION

• Lifting of heavy weights might damage the musculoskeletal system.

4.5 Transport of the ANLIKER XXL vegetable cutter

CAUTION!

The ANLIKER XXLvegetable cutter stands on wheels and can be easily transported from one place to another. Remember to open the caster wheel brakes to relocate the vegetable cutter. At its new place of use, secure stability by snapping in the brake catches.

Release the brakes only if the device needs to be moved!

Generated:	Reviewed:	Revised:	Status: 300 released	Page 15 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



4.6 Assembly and installation

Ensure ergonomic work situations: Always place the device on a plane and solid surface with a minimum size of 800 mm x 1100 mm.

Leave sufficient space around the vegetable cutter to swing open the funnel for the exchange of cutting discs, grating discs and dicing insert.

Connect the machine as close as possible to the power outlet. Avoid tripping hazards! Do not route the cables where people walk frequently!

If you are uncertain about the installation site and/or have questions regarding installation itself, please contact Brunner-Anliker AG (the contact address is provided on page 6 or 33).



Fig. 15: Power cable

4.7 Electrical / electronic configuration

The ANLIKER XXL vegetable cutter comes with an approx. 4-meter power cable which can be plugged into a 230-Volt socket (monophase connection).

To avoid tripping hazards, do not route the cable across passageways.

HAZARD

HAZARD!

- Defective electrical components may be live and pose a life-threatening hazard.
- Do not drive over, crush or pull on the cable(s).
- Disconnect the device from the mains supply before working on the electrical equipment.
 - Eliminate defects on electric components / modules immediately. In the event of acute danger, the equipment must not used. Never use the device in defective or inadequate condition.

CAUTION

CAUTION!

• Please observe the electrical data on the nameplate (see also page 7) before connecting the device to the mains supply.

Note

- Brunner-Anliker AG does not accept any liability for events and damages originating from electrical installation
- Protection against unexpected start-up: observe the national regulations!

NOTE

Generated:	Reviewed:	Revised:	Status: 300 released	Page 16 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



4.8 Start-up

Please observe the following guidelines for first startup and test run.

• Ensure that there are no foreign bodies in the vegetable cutter's filler spouts!

HAZARD

HAZARD!



- Do not change or modify the ANLIKER XXL vegetable cutter or add any equipment which might impair the safety or function of the device Otherwise the device no longer complies with the CE standards.
- Check the ANLIKER XXL safety functions at regular intervals. Malfunctions may
 massively impair its functions and result in severe injury to personnel and/or
 damage to the machine!

CAUTION



CAUTION!

• Always adhere to the local accident prevention regulations!

NOTE

Note

• The user must have read and understood the operating manual and in particular the chapter on safety regulations before working with the machine.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 17 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



4.9 Storage

If the ANLIKER XXL vegetable cutter is not used for a longer period of time, observe the following conditions to keep it fully functional:

- The storage place must be dry and clean.
- The ANLIKER XXL vegetable cutter must not be exposed to extreme cold or heat.
- The device must be kept clean.
- The ANLIKER XXL vegetable cutter must be packed or covered against the ingress of dirt and dust.

NOTE Note Brunner-Anliker AG cannot be held liable for damages caused by corrosion due to improper storage, e.g. in moist rooms or similar.

Please contact our after-sales service before returning the machine into service after a prolonged period of standstill.

All mechanical parts need to be inspected. In particular:

- check all components for corrosion (and deterioration) damage.
- check all cutting discs for damage and cutting quality.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 18 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5 Installation of the attachment

The ANLIKER L vegetable cutter can be used for a myriad of jobs. Observe the following steps when inserting cutting discs, grating discs and dicing inserts:

WARNING

Cut injury due to sharp cutting faces



- The knives and tips of the grating disc perforations are extremely sharp and now lie open.
- Danger of cuts and skin abrasions!

Any already mounted attachments need to be removed before a new one can be installed. Separate the device from the power supply.

ANLIKER XXL attachment piece with hinge: push down the locking pin, insert the hinge until the pin moves out and locks in place.




Fig. 16: Insert the attachment piece

and lock

Close the attachment piece and lock with the locking lever.



Fig. 17: Locking the newly attached piece

Generated:	Reviewed:	Revised:	Status: 300 released	Page 19 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



Insert the screw blade

Pay attention to the two guide bolts when inserting the blade



Fig. 18 Inserting the screw blade

Mounting the funnel



Fig. 19: Mounting the funnel



Fig. 21: Fastening the funnel

Insert the funnel into the holder piece. Make sure it fits correctly



20: IN / OUT direction

Fasten and lock the funnel on the holder piece



Fig. 22: Safety lock closed

Generated:	Reviewed:	Revised:	Status: 300 released	Page 20 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA

Fig.



Fig. 23: Lock the funnel

Fasten and lock the funnel on the attachment piece. The screw blade must be inserted.



Fig. 24: Locked funnel

5.1 Correct insertion of the cutting discs, grating discs and dicing inserts

5.1.1 Preparation of the ANLIKER XXL for food processing



Open the latch and swing the funnel to the side. Open the locking lever and swing out the attachment piece.

- Fig. 25: Tilted funnel and attachment piece
- 5.1.2 Inserting the ejector or ejector disc



Prior to inserting the cutting disc, install the ejector or ejector disc. It sits correctly when it almost (but not quite) touches the bottom of the cutting chamber. Without ejector/ejector disc, the cut food accumulates beneath the cutting disc, the cutting disc is pushed up and might damage cutting head and knives.

Fig. 26: Inserted ejector

Generated:	Reviewed:	Revised:	Status: 300 released	Page 21 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5.1.3 Insertion of cutting or grating disc



Place the disc on the drive shaft. Turn the disc slightly until it engages with the pin on the drive shaft and sits correctly (observe upper flushness with the drive shaft). Correct cutting disc placement is possible only if disc hub and pin are absolutely clean..

Fig. 27: Inserted cutting disc

WARNING

WARNING



- The knives and tips of the grating disc perforations are extremely sharp and now lie open.
- Danger of cuts and skin abrasions!

NOTE

Note

• The discs fit the drive shaft perfectly. Never push of force them down on the drive shaft with an excess of pressure.

5.1.4 Close the attachment



Swing the attachment piece back in place and mount the screw blade. Ensure locking!

Fig. 28: Inserted screw blade

5.1.5 Closing the funnel



Swing the funnel back in place and lock. Ensure its perfect fit. The ANLIKER XXL is now ready for operation.

Fig. 29: Locked funnel

Generated:	Reviewed:	Revised:	Status: 300 released	Page 22 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5.1.6 Inserting the dicer grid

The pin on the upper part must lock in the indent in the dicer grid.





Fig. 30: Dicer grid indent

Fig. 31:Upper part pin

The dicer grid is in the correct position when the pin on the upper part locks in the dicer grid indent.



Fig. 32: Inserted dicer grid

Generated:	Reviewed:	Revised:	Status: 300 released	Page 23 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5.2 Cutting vegetables

Put a suitable container (food container 1/1) or a large trolley container or tray under the processed food outlet.

Switch on the device.

Fill vegetables into the funnel.



Fig. 33: Filling with vegetables



Fig. 34: Rocking the screw blade

Fill in vegetables as needed.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 24 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA

If vegetables get stuck in the funnel, take the handle of the screw blade and move the device back and forth (slight rocking movements) by hand.

Large vegetables should be cut in pieces sized to the opening of the passageway.



swiss 🚹 made



Fig. 35: Cover mounted onto the outlet

HAZARD!

HAZARD



• Do not reach into the outlet when the device is running!

- Danger of cutting or crushing hands and fingers
- The machine may only be operated with the outlet cover safely in place.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 25 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5.3 Using the accessories (Multifeeder insert)

The Multifeeder insert allows continuous filling and cutting of long products such as cucumbers.

5.3.1 Preparing the device for the Multifeeder



First swing out the funnel, remove. The screw blade must be removed as well. Then install the required cutting disc. Then insert the Multifeeder.

Fig. 36: Inserting the Multifeeder

Switch on the machine, fill in vegetables. Push the vegetables down with the plunger. Push the OFF button to stop the machine.

HAZARD



HAZARD!

- Do not reach into the outlet when the device is running!
- Danger of cutting or crushing hands and fingers.

5.3.3 Changing the Multifeeder cutting disc

For this purpose, the Multifeeder must be completely removed!

NOTE

Note

• For disc change, the Multifeeder must be completely removed.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 26 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



5.4 Using the accessories (neutral blade)

The neutral blade is used for comfortable cutting of cabbage.

5.4.1 Preparing the device for the use of the neutral blade



First place and lock the ring of the neutral blade.

Fig. 37: Ring for the neutral blade



Fasten the plunger to the holder piece, observe the IN / OUT direction.

Fig. 38: Insert the neutral blade plunger

5.4.2 Operating the neutral blade



Fig. 39: Plunger operation

Do not fill beyond the edge.

When the neutral blade is used, the device must always be switched on with the ON/OFF button!

Generated:	Reviewed:	Revised:	Status: 300 released	Page 27 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



6 System care "cleaning concept"

This chapter describes the cleaning procedure for the device and its cutting discs, grating discs and dicing inserts.

For cleaning, the user may dismantle the device only as far as described here.

Attachment piece and plunger can be removed and cleaned without the need of tools.

6.1 Cleaning the ANLIKER XXL vegetable cutter

The outside of the device can be simply hosed down (splashwater). If high-pressure cleaners are used, keep a distance of at least half a meter from the device.

6.2 Removing the top

Remove the attachment in reverse order to "Installation of the XXL attachment piece" on page 19.

The first step is to separate the device from the power supply.

Open the lock on the funnel holder and remove the funnel.

Pull the screw blades out of the attachment.

Unlock the hinge on the attachment.

Unlock the locking lever, open the hinge, remove the attachment.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 28 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



6.3 Cleaning the cutting discs, grating discs and dicing inserts (W)

Use the nylon brush included in the consignment to clean the cutting discs, the grating discs and the dicing inserts (dicing knives and dicer grid) under running water.

Never clean the dicer grid with metal objects or by tapping it on the edge of a table. Best clean the grid by putting it in a combi steam oven at 90 degrees for about 10 minutes. Then brush the vegetable residues off under running water (the brush is part of the consignment).

NOTE

Note

• Cleaning in the dishwasher might reduce the life of the knives.

6.3.1 Cleaning the dicer grid

After vegetable processing, the square grid holes are filled with vegetable residues. To remove vegetable or fruit remains, proceed as follows:

6.3.2 Residues in the dicer grid

Soft vegetable and fruit types such as tomatoes, peppers, pears, kiwis, bananas, avocados etc. are easily removed by holding the back of the grid under running water and brushing it with the brush included in the consignment.

6.3.3 Manual cleaning of the dicer grid

Insert the dicer grid without knife into the device. Hold the dicer grid with one hand (fingers on the outer rim). Remove the vegetables with the other hand by pushing a raw, long carrot horizon-tally onto and through the grid holes. Then hold the front of the grid under running water and brush the remaining vegetable pieces off with the brush included in the consignment. Pieces stuck in the holes near the grid edges can be removed with a thin wooden skewer.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 29 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



NOTE

Note

• Use food grade detergents only. (no industrial fat solvents)

WARNING

• WARNING



- Ensure that the device is switched off with the ON/OFF switch prior to any maintenance job.
- Disconnect from the mains!
- The ANLIKER XXL vegetable cutter must not be cleaned with a stream-jet or high-pressure washers.
- The use of aggressive cleaning agents is strictly prohibited.

CAUTION



CAUTION

- The knives are extremely sharp and now lie open.
- Danger of cuts and skin abrasions!

Generated:	Reviewed:	Revised:	Status: 300 released	Page 30 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



7 Mounting the cutting disc holder



The cutting disc holder can accommodate up to seven different cutting discs. Its simple fastening principle allows it to be installed right were it is needed.

Fig. 40: Cutting disc holder



The disc holder can be easily taken off and moved to its new site of operation.

It can be mounted vertically or horizontally to a stable wall.

Fig. 41: Wall-mounted cutting disc holder



The vegetable cutter is equipped with two hooks located below the EMERGENCY OFF button for easy attachment of the cutting disc holder.

Fig. 42: Mounting the cutting disc holder

Generated:	Reviewed:	Revised:	Status: 300 released	Page 31 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



8 Troubleshooting

The following chapter describes possible disturbances which might occur during operation, and their elimination.

8.1 Elimination of malfunctions

The machine is built to endure and therefore not very susceptible to malfunctions.. Action in case of malfunctions:

First measure in case of malfunctions: Switch off the device! In case of unpleasant smells, unplug the mains plug.

8.1.1 Device does not run

- 1. Check the socket function by connecting another device.
- 2. Check whether the EMERGENCY OFF button has been reset
- 3. Check whether the attachment piece has snapped in correctly
- 4. Check whether the locking lever is locked
- 5. If the device still does not work, contact a technician or the Brunner-Anliker after-sales service.
- 6. If all is OK, the button turns green.

The device is connected	
A problem occurred	Separate from the power supply. When the light goes out, re-connect to the power supply.

8.1.2 Device clogged

Nothing goes in, nothing comes out. Switch off the device, take apart and clean (see item 7).

8.1.3 The dicing insert W (dicer knife and grid) cannot be removed

The dicer knife bayonet catch was not unlocked correctly. Rotate the dicing knife carefully counterclockwise and keep in place to allow unlocking of the bayonet catch and simultaneous removal of both parts from below.

8.1.4 The cutting quality (surface structure) keeps deteriorating

If the quality of the cut diminishes, the respective cutting disc should be replaced. We provide attractive exchange options! Get in touch with us.

8.1.5 The knife does not move freely

- a) the hub is dirty and the knife does not sit correctly
- B) the ejector has not been inserted.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 32 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



8.1.6 Cutter bar broken

The cutter bars can break by impacts from other objects or by incorrect handling.

IMPORTANT. Always search for the knife or its parts when broken.

WARNING



- High risk of injury for the customer/guest. •
- The operator is responsible if such malfunctions occur. •

8.1.7 The device can no longer be switched off.

Push the EMERGENCY OFF button! Please contact a technician.

8.1.8 Service opening

The service flap (opening) may only be opened after clearance with the Brunner-Anliker AG service or development department as otherwise the warranty is void!




Fig. 43: Service opening

8.2 Service and information

Please contact our Service Line for all problems and questions that are not described or cannot be solved.

Address: Brunner-Anliker Maschinen AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Switzerland

T: +41 44 804 21 00

mail@brunner-anliker.com

More information on our website at

brunner-anliker.com

Generated:	Reviewed:	Revised:	Status: 300 released	Page 33 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9 Annex

9.1 Spare parts

Spare parts must meet the technical requirements specified by the manufacturer. This compliance is guaranteed for original spare parts. Use original spare parts only. Our warranty is void if third-party parts or parts which have not been approved in writing are used.

NOTE Note Some wear and spare parts are subject to delivery periods and may not always be available at short notice.

- Please note that the delayed availability of spare parts may result in consequential damage and production losses.
- Always indicate the device number, device type and item number when ordering spare parts.

9.2 Disposal

Dispose of the system, system parts, accessories and packaging in an environmentally compatible manner.

	NOTE				
Note					
•	Resource recycling instead of waste disposal!				
•	Prior to their disposal, clean the materials of substances that might en- danger health and environment.				
•	Bring metal parts to a metal collection point.				
•	Bring plastic parts to a plastic collection point.				
•	Bring electric parts to a collection point for electric components.				
•	See to professional disposal or contract a waste disposal company.				

If this operating manual does not answer all of your questions, please feel free to contact our aftersales service (see page 33).

Generated:	Reviewed:	Revised:	Status: 300 released	Page 34 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.3 Device transfer to third parties

All liabilities by Brunner-Anliker AG cease if the ANLIKER XXL vegetable cutter is sold and transferred to a third party.

9.4 Technical Specifications

Machine type	ANLIKER XXL vegetable cutter
Electrical connection	230 V 50/60Hz
Electric motor	0.75 kW /
Weight	100 kg
Protection category	IP X6
Dimensions L x W x H	1000 x 1010 x 1528 mm

 Table 6: Technical specifications ANLIKER XXL

9.5 Warranty

During the warranty period, the machine may only be repaired and maintained by the manufacturer. Upon request, the manufacturer may authorize certain exceptions in writing. The guarantee comprises only and exclusively the part to be replaced plus replacement at the producer site. The warranty exclusively relates to the part to be replaced and its replacement at the manufacturer's factory, but not to a service in connection with a warranty repair not conducted by the specialist staff at our service center (refer to page 33) or by the manufacturer plant itself

All warranty claims regarding the ANLIKER XXL vegetable cutter are subject to the Brunner-Anliker AG general terms and conditions. Wear parts or improper handling are not part of the guarantee.

Generated:	Reviewed:	Revised:	Status: 300 released	Page 35 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6 Documents

9.6.1 Dimensional drawing ANLIKER XXL




Fig. 44: Dimensional drawing ANLIKER XXL

Generated:	Reviewed:	Revised:	Status: 300 released	Page 36 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6.2 CE Conformity Declaration



Brunner-Anliker AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Schweiz

T +41 44 804 21 00 F +41 44 804 21 90 mail@brunner-anliker.com brunner-anliker.com

EG-Konformitätserklärung

CE Déclaration de conformité EC Declaration of conformity

Wir / Nous / We,	Brunner-Anliker AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Schweiz
erklären in alleiniger Verantwortung, dass das Produkt déclarons de notre seule responsabilité que le produit bearing sole responsibility, hereby declare that the product	Beschreibung des Produkts Gemüseschneidemaschine Description du produit Machines coupe-légumes
inklusiv Schneidscheiben auf Rechnung inclus les disques mentionnés sur facture including Discs mentioned on invoice	Description of product Vegetable cutting machines Typenreihe / Série type / Type series ANLIKER XXL / XXL PRO
auf das sich diese Erklärung bezieht, mit der/den folgenden I auquel se rapporte la présente déclaration est conforme aux normes o referred to by this declaration is in conformity with the following stan Bestimmungen der Richtlinie Désignation de la directive	ou aux documents normatifs suivants.
provisions of the directive	titre et/ou numéro ainsi que date d'émission de la/des norme(s) : title and/or number and date of issue of the standard(s):
2006/42/EG: Maschinenrichtlinie 2006/42/CE: directive Machines 2006/42/EC: Machinery Directive	DIN EN ISO 12100:2011-03 DIN EN ISO 13849-1:2016-06 DIN EN ISO14119:2014-03 DIN EN 1672-1 :2014-12
2014/30/EU Richtlinie 2011/63/EU	DIN EN 1672-2 :2009-07 DIN EN 1678 :2011-02 DIN EN 35014-1 :2018-08 DIN EN 35014-2 :2018-01 DIN EN 60204-1 :2007-06 DIN EN 60335-1 :2012-10
Mitteilung über Anerkennung der Qualitätssicherung: Communication sur la reconnaissance de l'assurance de la qualité: Report on the acknowledgment of the quality assurance:	

Augestellt	Geprüft:	Geändert:	Status: 300 Freigegeben	Selte: 1
Ralph Moretti	Michel Benkovics		Unterlagennummer:	Index
23.08.2021	25.08.2021	05.12.2022		BA

Fig. 45: CE Conformity Declaration

Generated:	Reviewed:	Revised:	Status: 300 released	Page 37 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6.3 CE Conformity Declaration for accessories



 Brunner-Anliker AG
 T +41 44 804 21 00

 Flughofstrasse 55
 F +41 44 804 21 90

 8152 Opfikon-Glattbrugg
 mail@brunnr-anliker.com
 Schweiz

brunner-anliker.com

EG-Konformitätserklärung

CE Déclaration de conformité

EC Declaration of conformity

Wir / Nous / We,	Brunner-Anliker AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Schweiz
erklären in alleiniger Verantwortung, dass das Produkt déclarons de notre seule responsabilité que le produit bearing sole responsibility, hereby declare that the product auf das sich diese Erklärung bezieht, mit der/den folgenden	
auquel se rapporte la présente déclaration est conforme aux normes referred to by this declaration is in conformity with the following sta	
Bestimmungen der Richtlinie Désignation de la directive provisions of the directive 2006/42/EG: Maschinenrichtlinie 2006/42/EC: Maschines 2006/42/EC: Machinery Directive 1933/2004 2023/2006	Titel und/oder Nummer sowie Ausgabedatum der Norm(en): titre et/ou numéro ainsi que date d'émission de la/des norme(s) : title and/or number and date of issue of the standard(s):
Mitteilung über Anerkennung der Qualitätssicherung: Communication sur la reconnaissance de l'assurance de la qualité: Report on the acknowledgment of the quality assurance:	Ergänzung zu Anliker XXL / XXL PRO
Ausstellung: Brunner-Anliker SA Ralph Moretti / PCO Via in Paes 82 6372 Quartino, Schweiz	Opfikon, Dezember 2022 M. Benkovics

Augestellt	Geprüft:	Gelindert:	Status: 300 Freigegeben	Selte: 1
Raiph Moretti	Michel Benkovics		Unterlagennummer:	Index
26.08.2021	07.09.2021	05.12.2022		BA

Fig. 46: Conformity Declaration for accessories

Generated:	Reviewed:	Revised:	Status: 300 released	Page 38 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6.4 Supplement 1935/2004



Brunner-Anliker AG Flughofstrasse 55 8152 Opfikon-Glattbrugg mail@brunnr-anliker.com Switzerland

T +41 44 804 21 00 F +41 44 804 21 90 brunner-anliker.com

Declaration of Conformity

as set forth in EC directive 1935/2004

for objects that come into contact with food

We hereby declare that all system components which are part of machine ANLIKER XXL und XXL Pro and come into contact with the products, including those which are incorporated or replaced at a later point in time, fully comply with the requirements set forth in EC directive 1935/2004 (in its applicable version).

Under normal and foreseeable conditions, the components that come into contact with the products are transferred to food in such a way that they do not imperil human health.

Neither do they cause an unacceptable change to the food composition, nor do they affect or hinder its investigation by the human senses without the use of technical or other auxiliary means.

This declaration is not valid if changes have been carried out without the consent of the manufacturer.

Published by Brunner-Anliker SA		Opfikon, Dezember 2022
Ralph Moretti / PCO Via in Paes 82 6372 Quartino, Schweiz	R. Morel	M. Benkovics
	•	Technischer Direktor / Technical Director

Generated:	Reviewed:	Revised	Status: 300 released	Page: 1
Raiph Moretti	Michel Benkovics	Ralph Moretti	Document number:	Index
09 Jan 2019	09 Jan 2049	05.12.2022		BA

Fig. 47: Supplement 1935/2004

Generated:	Reviewed:	Revised:	Status: 300 released	Page 39 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6.5 Supplement



Brunner-Anliker AG Flughofstrasse 55 8152 Opfikon-Glattbrugg Switzerland T +41 44 804 21 00 F +41 44 804 21 90 mail@brunnr-anliker.com brunner-anliker.com

Declaration of Conformity

as set forth in EC directive Nr. 10/2011 Art.15

for objects that come into contact with food

We hereby declare that all system components which are part of machine ANLIKER XXL und XXL Pro and come into contact with the products, including those which are incorporated or replaced at a later point in time, fully comply with the requirements set forth in EC directive Nr. 10/2011 Art.15 (in its applicable version).

Under normal and foreseeable conditions, the components that come into contact with the products are transferred to food in such a way that they do not imperil human health.

Neither do they cause an unacceptable change to the food composition, nor do they affect or hinder its investigation by the human senses without the use of technical or other auxiliary means.

This declaration is not valid if changes have been carried out without the consent of the manufacturer.

Published by Brunner-Anliker SA Raiph Moretti / PCO Via in Paes 82 6372 Quartino, Schweiz

R. Morel

Opfikon, Dezember 2022 M. Benkovics Technischer Direktor / Technical Director

Generated:	Reviewed:	Revised	Status: 300 released	Page: 1
Ralph Moretti	Michel Benkovics	Raiph Moretti	Document number:	Index
09 Jan 2019	09 Jan 2049	05.12.2022		BA

Fig. 48: Supplement 10/2011

Generated:	Reviewed:	Revised:	Status: 300 released	Page 40 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA



9.6.6 Supplement



Brunner-Anliker AG
 Brunner-Anliker AG
 T +41 44 804 21 00

 Flughofstrasse 55
 F +41 44 804 21 90

 8152 Opfikon-Glattbrugg
 mail@brunnr-anliker.com
 Switzerland

T +41 44 804 21 00 brunner-anliker.com

Manufacturer self-declaration

as set forth in directive WEEE 2012/19/EU

We hereby declare that machine ANLIKER XXL and XXL Pro complies with the fundamental requirements set forth in directive WEEE (2012/19/EU (in its applicable version).

Published by Brunner-Anliker SA		Opfikon, Dezember 2022
Ralph Moretti / PCO Via in Paes 82 6372 Quartino, Schweiz	R. Morel	M. Benkovics
	•	Technischer Direktor / Technical Director

Generated:	Reviewed:	Revised	Status: 300 released	Page: 1
Raiph Moretti	Michel Benkovics	Raiph Moretti	Document number:	Index
09 Jan 2019	09 Jan 2019	05.12.2012		0A

Fig. 49: Supplement WEEE

Generated:	Reviewed:	Revised:	Status: 300 released	Page 41 of 41
Ralph Moretti		Ralph Moretti	Document number:	Index
28 July 2021		20.01.2025	235.01550	CA